Fifo Write/Read

Contents

1 Introduction

What: Emplementing the "fifo" ping utility.
Binary located at:

- *libLDA/run/fifo*

This binary is used to test the uploading connection.

2 Single test

```
# run/fifo poldhcp54.conf -snf

Fifo (    6):      0%  [ 1,5] [ 1,8]

*** Total : miss 0 / 6 Pkts = 0%
 DIF [ 1,5] : 3 received + 0 missing 3 pkts and 0 errors.
 DIF [ 1,8] : 3 received + 0 missing 3 pkts and 0 errors.
 Dropped pkts:    0
 Unexpected pkts: 0
```

3 Non regression test

```
# run/fifo poldhcp54.conf -f

Flush: [buff] [ 1,5] [ 1,8]
Flush(    2):      0%      0      0
Fifo (   12):      0%  [ 1,5] [ 1,8]
Fifo (   12):      0%  [ 1,5] [ 1,8]
Fifo (   12):      0%  [ 1,5] [ 1,8]

*** Total : miss 0 / 38 Pkts = 0%
 DIF [ 1,5] : 18 received + 0 missing 18 pkts and 0 errors.
 DIF [ 1,8] : 18 received + 0 missing 18 pkts and 0 errors.
 Dropped pkts:    0
 Unexpected pkts: 0
```